

Synology®

Synology Remote

使用手冊

Remote08312010

目錄

- 3 歡迎您！
- 4 Synology Remote 概觀
- 5 包裝內容物
- 6 使用入門
- 8 使用 Synology Remote 遙控器聆聽音樂
- 11 Synology Remote 遙控器規格

想要參閱其他語言版本的使用手冊嗎？請造訪
<http://www.synology.com/support/download.php>

歡迎您！

恭喜您購買 Synology Remote 遙控器。本產品是設計用來與您的 Synology DiskStation 搭配使用。只要將 USB 喇叭或家用立體聲音響接到 Synology DiskStation 上，您便可以使用 Synology Remote 遙控器來播放 Synology DiskStation 或 iPod 上存放的音樂，也可以收聽網路廣播電台。



遙控器



Audio Dock



包裝內容物

請檢查包裝盒內是否包含下列各個項目。

遙控器 x 1



迷你 USB 接線 x 1



鈕釦電池 x 1



Audio Dock x 1




使用手冊 x 1



使用入門

連接 Audio Dock

- 1 將 USB 接線連接至 audio dock 的迷你 USB 接頭埠。



- 2 將 USB 接線的另一端連接至 Synology DiskStation 的 USB 埠。



- 3 將鈕釦電池放入遙控器中。請確認有「+」的一面是面向上方。



4 檢查遙控器是否已經與 audio dock 正確配對。

- 如果您按下遙控器上的任何按鈕時，audio dock 的藍色 LED 指示燈開始閃爍，即表示 Remote 已經與 audio dock 正確配對。
- 否則，請按下 audio dock 上的配對按鈕。此時，LED 指示燈會亮起。同時按下遙控器上的上一首 (◀◀) 及下一首 (▶▶) 按鈕，直到藍色 LED 指示燈開始閃爍為止。

注意：如果在您按一次按鈕時，遙控器的 LED 指示燈會連續閃爍 5 次，即表示遙控器的電力不足。請使用 CR2032 型鈕釦電池來更換遙控器內的電池。

連接喇叭

若要將聲音輸出裝置連接至 audio dock 上，您可以選擇下列的聲音輸出選項：

- 1 **3.5mm 音訊插孔連頭埠：**可用來連接喇叭或耳機。
- 2 **S/PDIF 連頭埠：**可用來連接數位音訊裝置，例如家用立體聲音響。
- 3 **USB 2.0 埠：**可用來連接 USB 喇叭。

注意：

- DiskStation 會將 USB 喇叭視為預設的聲音輸出裝置。若要使用 3.5mm 音訊插孔或 S/PDIF 接頭埠，請先中斷 USB 喇叭與 DiskStation 之間的連線。
 - 如需建議使用的 USB 喇叭，請造訪 www.synology.com。
 - 若要在使用 S/PDIF 時獲得最佳的音質，請使用遙控器將音量調至最大。
-

使用 Synology Remote 遙控器聆聽音樂


管理音樂

如果這是您初次使用 DiskStation，或者您尚未啟動 Audio Station，請依照下列步驟的指示來啟用 Audio Station：

- 1 登入 DiskStation Manager 3.0 (以下簡稱為「DSM」) 或以上版本。如果您使用的不是 DSM 3.0 或以上版本，請下載最新的 DSM，位於：www.synology.com。
- 2 請前往主選單 > 控制台 > **Audio Station**。勾選**啟動 Audio Station 2** 核取方塊並按一下**確定**。系統會在 DiskStation 上建立「**music**」共用資料夾。



- 3 開啟 [檔案總管] 並將聲音檔案上傳至 Synology DiskStation 上的「**music**」共用資料夾。



- 4 現在您可以開始使用 Synology Remote 遙控器聆聽音樂。

注意：如需更多 Audio Station 設定的相關資訊，請參閱 DSM 的說明文件或使用手冊。

播放 Synology DiskStation 的音樂

- 請按下遙控器上的任何一個功能按鈕來選擇並播放音樂：
 - Random100**：聆聽 DiskStation 隨機選出的 100 首歌曲。
 - Playlist**：聆聽播放清單中整理的歌曲。若要跳至下一個播放清單，請按住前一首 (◀) 及下一首 (▶) 按鈕，直到曲目變更為止。如需更多設定播放清單的相關資訊，請參閱 Audio Station 的說明文件。
 - Radio**：收聽您在**我的最愛**區塊中新增的網路電台。Audio Station 隨附預設的網路電台清單。如果您沒有將任何廣播電台加到我的喜愛中，則系統會串流播送預設的網路電台。
 - iPod**：在 iPod 連接至 Synology DiskStation 的 USB 埠時，依照目錄順序播放 iPod 中的歌曲。
- Synology Remote 遙控器是在「USB 模式」下運作，使用 Synology DiskStation 的 USB 埠上連接的裝置播放音樂。若要以視覺方式進行互動式音樂播放，請展開 Audio Station 右側的佇列面板。



注意：如需更多播放清單或網路電台的相關資訊，請參閱 Audio Station 的說明文件或使用手冊。

設定遙控器的熱鍵功能

遙控器上有 4 個遙控熱鍵。使用這些熱鍵，您可以快速存取喜愛的播放清單、智慧型播放清單或網路電台。您可以使用兩種方式設定這些熱鍵：

方法 A：

- 1 使用遙控器播放任何**播放清單**中的音樂或**網路電台**時，請按住任何熱鍵，直到您聽到 DiskStation 發出嗶聲為止。
- 2 目前使用的播放清單會儲存為熱鍵。
- 3 您可多按住對應的熱鍵來立即播放該播放清單中的音樂。

方法 B：

- 1 從 DSM 操作介面中進入 **Audio Station**。
- 2 按一下左側面板上的**播放清單**、**智慧型播放清單**或**網路電台**。可用的播放清單或網路廣播電台會顯示在中央面板中。
- 3 在中央面板中，請以右鍵點按您想設為遙控器熱鍵的播放清單或網路廣播電台。
- 4 在顯示的選單中，請將您的滑鼠移至設為 **Remote 熱鍵**。畫面上會顯示子選單。



- 5 選擇一個熱鍵來進行設定。各個熱鍵項目之前的圓點與遙控器上的熱鍵按鈕相對應。
- 6 設定完成之後，您現在可以按下對應的熱鍵來立即播放該播放清單中的音樂。

注意：針對網路電台，請以右鍵點按您想設為遙控器熱鍵的廣播電台。

更多資訊

恭喜您！您現在可以開始使用 Synology Remote 遙控器了。如需更多資訊或線上資源，請造訪 www.synology.com。

Synology Remote 遙控器規格

如需最新的產品規格，請造訪 www.synology.com

大小及重量

大小 (厚度 x 寬度 x 高度) (公釐)	遙控器：115mm x 55mm x 14.3mm Audio Dock：54.6mm x 54.6mm x 20.5mm
------------------------	--

重量	遙控器：55g Audio Dock：30g
----	---------------------------

Audio Dock 輸入 / 輸出介面

聲音輸出類型	3.5mm 立體聲音訊插孔 光纖 S/PDIF 輸出 USB 介面 (相容於 1.1/2.0)
--------	---

迷你 USB 接頭埠	用來連接 DiskStation
------------	------------------

聲音品質

解析度	16 位元立體聲 DAC
取樣頻率	48/44.1 KHz

射頻效能

頻率範圍	2.4GHz ~ 2.483 GHz
頻道	16 多重聲道
傳輸距離	30 公尺不限方向的射頻訊號

電池	可更換的鈕釦式鋰電池 CR2032 3V
----	----------------------

認證機構

CE、FCC

Federal Communication Commission Interference Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and audio dock.
3. Connect the equipment into an outlet on a circuit different from that to which the audio dock is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

LIMITED WARRANTY

Synology warrants that every hardware portion of the Products will be free from physical defects in material and workmanship within warranty period, or the Product will be repaired or replaced as determined solely by Synology. The Synology Remote has two years warranty from the purchase date. For more detailed information, please visit <http://www.synology.com>.

COPYRIGHT NOTICE

All title, copyright and other intellectual property rights in and to any Synology Products, the "Products" or "Product" (including but not limited to product design and appearance, firmware, and any relevant media, images, photographs, animations, video, audio, music, text, and applets incorporated into the Products), the accompanying manuals and other documents, and on-line or electronic documents, if any, are owned by Synology Inc. Unless otherwise expressly licensed by Synology Inc. in writing, any provision of the Products does not represent any license of any of the above rights.

Copyright © 2010 Synology Inc.; All rights reserved.

TRADEMARK NOTICE

Synology and other names of Synology Products are proprietary marks or registered trademarks of Synology Inc. Microsoft, Windows series, and Internet Explorer are trademarks of Microsoft Corporation. Apple, Mac, Mac OS series are trademarks of Apple Computer, Inc., registered in the U.S. and other countries. Other products and company names mentioned herein are trademarks of their respective holders.

REVISIONS

Synology reserves all rights to revise or update its Products, other products, software, or related documentation without further notice.

Synology Inc. reserves the right to revise this publication and to make changes in the content hereof without the obligation to notify any person of such revision or changes.

